

After Season Maintenance of Alpine Liquid Systems

... service the same as a sprayer ...

1. Flush **PUMP** with water and remove from drill
 - Remove water from pump and store with RV anti-freeze.
 - Check oil level - should be at the bottom of the dip stick - no higher.
 - Should there be any trace of oil around the drive shaft – replace the seal.
2. Flush **MANIFOLD** with water & blow with air – *blowing w/air is a must!*
 - Empty water from manifold to prevent freezing. You can do this by opening the end of the manifold & blowing out w/air. Unscrew the large black nut and turn the manifold down and drain water.
 - Remove screen body assembly. Clean & store inside.
3. Clean main filter **SCREEN**.
4. Empty & clean Alpine **TANK** on air drill or cart (depending on where it is located).



the starter fertilizer company

800-265-2268
www.alpineplantfoods.com